Equipment Packages

tandard: ■ ptional: □	Powe	Profi	Profi+
Engine	_	_	_
Preheater unit (engine, transmission oil)			
Transmission			
Shuttle function, stop-and-go function			
Reverse Alarm			
Guidance system			
Guidance system basic package			
Standard Trimble / NovAtel			
RTK Trimble / NovAtel			
TI Auto			
Contour Assistant			
Agronomy			
Agronomy basic package			
Telemetry			
Telemetry basic package			
Machine control			
Machine control basic package			
Section Control			
Variable Rate Control			
Vario operation			
Multi-function joystick with cruise control, engine speed memory,	_	_	_
automatic modes, controls for hydraulics	ш	_	ш
3L joystick			
Individual Operation Manager – flexible key assignment			
Digital Dashboard			
12" terminal with touchscreen and key control			
Second 12" terminal in roof			
Fendt Active steering			
Cab			
Active charcoal filter			
Mechanical cab suspension			
Pneumatic cab suspension			
0 () () () ()			
Super comfort seat 3-point belt			

	Power	Profi	Profi+
	9	4	4
Air-conditioning			
ntegrated automatic climate control			
Split windscreen and door on right			
Continuous windscreen			
One-piece windscreen and door on right			
lear window wash/wipe			
lear view mirror and wide-angle mirror lectrically adjustable, heated			
Auxiliary device holder			
Universal mobile phone holder			
Jniversal tablet holder			
Radio mounting kit with two stereo speakers			
nfotainment package			
nfotainment bundle + 4.1 sound system			
camera connections (digital/analogue)			
USB ports			
Fendt Reaction steering system			
Brake level device			
lectric battery disconnect switch			
Chassis			
Front axle suspension self-leveling, lockable		п	
Steering brake			
Automatic trailer steering axle lock			
Compressed air system 2-circuit system			
4WD / differential locks			
Rear / front differential with 100% disc locking and steering angle sensors	-		
Power lift			
Sa front power lift, with external control (separate valve)			
Comfort front power lift da, with position control, external controls			
Comfort front power lift da, with position control and relief control, external controls			
Electrohydraulic power lift sa (EHR), with external controls			

	Power	ij	Profi+
РТО	Po	Profi	P
Rear PTO 540/540E/1000 rpm			
External controls for rear PTO			
PTO comfort control, electrohydr. preselection			
Hydraulics			
EHS valve actuation crossgate lever, multi-function joystick			
EHS valve actuation linear module*		П	П
External control for hydraulic control unit at rear			
Load sensing system with axial piston pump (110 l/min)			
1st and 2nd EHS valve at rear			
3rd EHS valve at rear			
4th EHS valve at rear or 3rd EHS valve at rear and 1st EHS valve in front			
Unpressurised rear return flow			
Rear DCUP couplings (connect under pressure)			
Front loader			
Front loader Cargo 4X/75			
Front loader Cargo 4X/75 Compact			

Fendt 300 Vario Series Specifications

		311 Vario	312 Vario	313 Vario	314 Vario
Engine					
Rated hp	kW/hp	60/81	68/91	74/99	85/114
Rated power ECE R 120	kW/hp	74/100	83/113	90/123	97/132
Rated power with DP ECE R 120 (approval rating)	kW/hp				104/142
Maximum power ECE R 120	kW/hp	83/113	90/123	98/133	104/142
Maximum power with DP ECE R 120	kW/hp				112/152
No. of cylinders	number	4	4	4	4
Cylinder bore/stroke	mm	108 / 120	108/120	108/120	108/ 120
Cubic capacity	cm³	4400	4400	4400	4400
Rated speed	rpm	2100	2100	2100	2100
Max. torque at 1500 rpm	Nm	497	536	571	608
Max. torque with DP at 1500 rpm	Nm				650
Torque rise	%	48.3	41.5	38.9	37.2
Fuel level	gallons	55.5	55.5	55.5	55.5
DEF tank	gallons	6.0	6.0	6.0	6.0

HallSillission and PTO		
Speed range forward	km/h / mph	0.02-40 / 65 ft./hr25
Speed range reverse	km/h / mph	0.02-25 / 65 ft./h-15 mph
Rear PTO		540/ 540E/ 1000
Rear PTO option (including ground speed PTO)		540/1000/4,2

I/min / GPM	110/29	110/29	110/29	110/29
PSI	2,900	2,900	2,900	2,900
number	0/0/4	0/0/4	0/0/4	0/0/4
number	1/0/3	1/0/3	1/0/3	1/0/3
litres	43	43	43	43
daN	5960	5960	5960	5960
daN	3130	3130	3130	3130
	PSI number number litres daN	PSI 2,900 number 0/0/4 number 1/0/3 litres 43 daN 5960	PSI 2,900 2,900 number 0/0/4 0/0/4 number 1/0/3 1/0/3 litres 43 43 daN 5960 5960	PSI 2,900 2,900 2,900 number 0/0/4 0/0/4 0/0/4 0/0/4 number 1/0/3 1/0/3 1/0/3 litres 43 43 43 daN 5960 5960 5960

Dimensions					
Front track width (standard tires)	mm	1685	1685	1820	1820
Rear track width (standard tires)	mm	1660	1660	1800	1800
Overall width with standard tires	mm	2220	2220	2320	2320
Overall length	mm	4336	4336	4336	4336

		311 Vario	312 Vario	313 Vario	314 Vario
Overall cab height with standard tires without Fendt Guide	mm	2820	2820	2860	2860
Overall cab height with standard tires with Fendt Guide	mm	2870	2870	2910	2910
Max. ground clearance	mm	510	510	510	510
Wheelbase	mm	2420	2420	2420	2420
Weights					
Unladen weight (hase tractor with cah - full tanks					

Max. permissible overall weight



30 | fendt.com